



# AERO CONTROLS

## PRODUCTS

**Parts, Tooling, Assets - In STOCK**

**Contact: [parts@aero-controls.com](mailto:parts@aero-controls.com)**

**+61 439 038 065**

<b>Part No</b>	<b>Descriptions</b>
106C7156P04	LM2500 SHIPPING CONTAINERS
10-392775-5	EXCITER, IGNITION 07482SOCNL21454P05 MFR59501 S/N: LG4546
124T5712P0001	FTD 325 - NA CLASS I DIV 2
124T5712P0002	FTD 325 - NA CLASS I DIV 1
16925	CABLE: TYPE EXTENSION
199D3591G001	SIDE SEAL
227B6085G004	PIN. BORESCOPE
28VDCPS1	POWER CARD (PHOENIX CONTACT, OUTPUT DC24V40A)
354A1513P186	IGNITOR CABLE
362A1052P104	FLAME SENSOR (UV)
362A1052P106	FLAME SENSOR (UV)
362A1052P107	FLAME SENSOR (UV)
362A1053P031	FLAME SENSOR CABLE
362A1053P036	FLAME SENSOR CABLE
362A3342P002	FLAME SENSOR CABLE
362A3342P005	FLAME SENSOR CABLE
379A8057P001	LARGE HYD 3-WAY VALVE
514.001.063	INPUT MODULE EX1800
5437-092	NETCON POWER SUPPLY
5437-507	2-LINE DISPLAY
5466-1000, REV:D	POWER SUPPLY, 2 SLOT, 24VDC
5466-1050	MICRONET SPEED/ANALOG I/O
5466-5000	MODULE - MICRONET SPEED SENSOR
5466-5027	MODULE - MICRONET SIMPLEX
5501-1432, REV:B	2CH ACTUATOR CONTROLLER
6072T47P07	LM1600 LIQUID FUEL NOZZLE
6072T47P08	LM1600 LIQUID FUEL NOZZLE
64/07010441/16	CABLE FROM RH XNSD SPEED SENSOR
6601-01-109-0	HILLIARD CLUTCH ASSEMBLY
66464SOCN106C7154G04	LM6000 SHIPPING CONTAINERS
8580-042	2057 PUMP

8580-053	2057 PUMP
8580-059	CIT / CDP Sensor
8580-064	CIT / CDP Sensor
8580-066	2057 PUMP
8580-067	CIT / CDP Sensor
8580-071	2057 PUMP
8580-080	2057 PUMP
8580-082	2057 PUMP
8580-083	2057 PUMP
8580-085	2057 PUMP
8580-086	2057 PUMP
8904-166	1907 Small Gas Valve (valve only)
8904-218	CIT / CDP Sensor
8904-238	1907 Small Gas Valve (valve only)
8904-245	CIT / CDP Sensor
8904-257	CIT / CDP Sensor
8904-289	1907 Small Gas Valve (valve only)
8904-303	1907 Small Gas Valve (valve only)
8904-305	1907 Small Gas Valve (valve only)
8904-371	1907 Small Gas Valve (valve only)
8904-390	1907 Small Gas Valve (valve only)
8904-418	1907 Small Gas Valve (valve only)
8904-433	1907 Large Liquid Valve & Actuator
8904-444	1907 Small Gas Valve (valve only)
8904-484	1907 Small Gas Valve (valve only)
8904-558	3103 Valve c/w TM55 Actuator
8904-614	1907 Small Gas Valve (valve only)
8904-625	3103 Valve c/w TM55 Actuator
8904-627	3103 Valve c/w TM55 Actuator
8904-632	1907 Small Liquid Valve
8904-665	3171 Valve c/w Actuator
8904-730	1907 Small Gas Valve (valve only)
8904-732	3103 Valve c/w TM55 Actuator
8904-736	3171 Valve c/w Actuator
8904-752	3103 Valve c/w TM55 Actuator
8904-773	3103 Valve c/w TM55 Actuator
8904-780	3103 Valve c/w TM55 Actuator
8904-786	1907 Large Liquid Valve & Actuator
8904-787	3103 Valve c/w TM55 Actuator
8904-831	3103 Valve c/w TM55 Actuator
8904-838	3103 Valve c/w TM55 Actuator
8904-847	3103 Valve c/w TM55 Actuator
8904-922	1907 Large Liquid Valve & Actuator
8904-931	3103 Valve c/w TM55 Actuator
8904-941	3151A WATER VALVE
8904-944	1907 Small Gas Valve (valve only)
8904-945	1907 Small Gas Valve (valve only)

8904-956	1907 Small Gas Valve (valve only)
8904-959	3151A WATER VALVE
8904-967	3103 Valve c/w TM55 Actuator
8915-011	3103 Valve c/w TM55 Actuator
8915-012	3151A WATER VALVE
8915-017	3103 Valve c/w TM55 Actuator
8915-026	3103 Valve c/w TM55 Actuator
8915-038	3103 Valve c/w TM55 Actuator
8915-039	3103 Valve c/w TM55 Actuator
8915-046	1907 Large Liquid Valve & Actuator
8915-057	1907 Small Gas Valve (valve only)
8915-063	1907 Small Gas Valve (valve only)
8915-077	1907 Small Gas Valve (valve only)
8915-083	3151A WATER VALVE
8915-094	3103 Valve c/w TM55 Actuator
8915-1008	3103 Valve c/w EM35 Actuator
8915-1009	3103 Valve c/w EM35 Actuator
8915-1010	3103 Valve c/w EM35 Actuator
8915-1023	3151A WATER VALVE
8915-1024	3151A WATER VALVE
8915-1025	3103 Valve c/w EM35 Actuator
8915-1026	3103 Valve c/w EM35 Actuator
8915-1027	3103 Valve c/w EM35 Actuator
8915-1029	3103 Valve c/w EM35 Actuator
8915-103	3151A WATER VALVE
8915-1034	3103 Valve c/w TM55 Actuator
8915-106	1907 Small Gas Valve (valve only)
8915-111	3103 Valve c/w TM55 Actuator
8915-1144	3151A WATER VALVE
8915-1145	3103 Valve c/w EM35 Actuator
8915-1146	3103 Valve c/w EM35 Actuator
8915-1148	3171 Valve c/w Actuator
8915-1149	3171 Valve c/w EM35 Actuator
8915-1151	3171 Valve c/w EM35MR1 Actuator
8915-1152	3103 Valve c/w EM35 Actuator
8915-1154	3103 Valve c/w EM35 Actuator
8915-1156	3103 Valve c/w TM55 Actuator
8915-1160	3103 Valve c/w EM35 Actuator
8915-118	3151A WATER VALVE
8915-1185	3103 Valve c/w EM35 Actuator
8915-1193	3171 Valve c/w Actuator
8915-1194	3171 Valve c/w Actuator
8915-1206	3103 Valve c/w EM35 Actuator
8915-123	3103 Valve c/w TM55 Actuator
8915-135	3103 Valve c/w TM55 Actuator
8915-148	3103 Valve c/w TM55 Actuator
8915-151	3103 Valve c/w TM55 Actuator

8915-158	1907 Small Gas Valve (valve only)
8915-173	3103 Valve c/w TM55 Actuator
8915-185	3103 Valve c/w TM55 Actuator
8915-190	3103 Valve c/w TM55 Actuator
8915-191	3103 Valve c/w TM55 Actuator
8915-194	3151A WATER VALVE
8915-305	3103 Valve c/w TM55 Actuator
8915-329	1907 Small Gas Valve (valve only)
8915-348	3103 Valve c/w TM55 Actuator
8915-355	1907 Large Liquid Valve & Actuator
8915-358	TM Steam Valve
8915-365	TM Steam Valve
8915-367	TM Steam Valve
8915-369	TM Steam Valve
8915-370	TM Steam Valve
8915-371	TM Steam Valve
8915-413	3103 Valve c/w TM55 Actuator
8915-416	3103 Valve c/w TM55 Actuator
8915-425	1907 Small Gas Valve (valve only)
8915-428	1907 Small Gas Valve (valve only)
8915-429	3151A WATER VALVE
8915-431	1907 Small Gas Valve (valve only)
8915-438	1907 Small Gas Valve (valve only)
8915-454	3151A WATER VALVE
8915-489	1907 Large Liquid Valve & Actuator
8915-514	3103 Valve c/w TM55 Actuator
8915-517	1907 Small Gas Valve (valve only)
8915-520	3151A WATER VALVE
8915-526	3103 Valve c/w TM55 Actuator
8915-527	1907 Small Gas Valve (valve only)
8915-539	3103 Valve c/w TM55 Actuator
8915-559	3103 Valve c/w TM55 Actuator
8915-573	3103 Valve c/w TM55 Actuator
8915-584	3171 Valve c/w Actuator
8915-598	3103 Valve c/w TM55 Actuator
8915-600	1907 Small Gas Valve (valve only)
8915-627	1907 Small Gas Valve (valve only)
8915-628	3151A WATER VALVE
8915-639	3103 Valve c/w TM55 Actuator
8915-640	3103 Valve c/w TM55 Actuator
8915-645	1907 Small Gas Valve (valve only)
8915-652	1907 Large Liquid Valve & Actuator
8915-656	3103 Valve c/w TM55 Actuator
8915-669	3171 Valve c/w EM35 Actuator
8915-671	3103 Valve c/w TM55 Actuator
8915-673	3151A WATER VALVE
8915-674	1907 Large Liquid Valve & Actuator

8915-679	3171 Valve c/w Actuator
8915-689	3151A WATER VALVE
8915-698	3103 Valve c/w TM55 Actuator
8915-703	3103 Valve c/w EM35 Actuator
8915-708	3103 Valve c/w TM55 Actuator
8915-712	3103 Valve c/w TM55 Actuator
8915-714	3103 Valve c/w TM55 Actuator
8915-721	3103 Valve c/w TM55 Actuator
8915-722	3103 Valve c/w TM55 Actuator
8915-728	3171 Valve c/w Actuator
8915-731	3103 Valve c/w TM55 Actuator
8915-741	3103 Valve c/w EM35 Actuator
8915-747	3171 Valve c/w EM35 Actuator
8915-770	3103 Valve c/w TM55 Actuator
8915-773	1907 Small Gas Valve (valve only)
8915-775	3151A WATER VALVE
8915-780	3103 Valve c/w TM55 Actuator
8915-782	3151A WATER VALVE
8915-791	3171 Valve c/w EM35 Actuator
8915-815	1907 Large Liquid Valve & Actuator
8915-839	1907 Large Liquid Valve & Actuator
8915-843	3151A WATER VALVE
8915-845	1907 Small Gas Valve (valve only)
8915-849	3151A WATER VALVE
8915-856	1907 Large Liquid Valve & Actuator
8915-859	1907 Small Gas Valve (valve only)
8915-864	1907 Large Liquid Valve & Actuator
8915-870	3103 Valve c/w TM55 Actuator
8915-872	1907 Small Gas Valve (valve only)
8915-877	1907 Large Liquid Valve & Actuator
8915-878	1907 Small Gas Valve (valve only)
8915-879	3151A WATER VALVE
8915-880	3103 Valve c/w EM35 Actuator
8915-881	3151A WATER VALVE
8915-883	1907 Large Liquid Valve & Actuator
8915-884	3151A WATER VALVE
8915-886	3103 Valve c/w EM35 Actuator
8915-887	3103 Valve c/w TM55 Actuator
8915-889	3103 Valve c/w TM55 Actuator
8915-894	3103 Valve c/w EM35 Actuator
8915-896	3103 Valve c/w TM55 Actuator
8915-898	3103 Valve c/w TM55 Actuator
8915-904	3103 Valve c/w TM55 Actuator
8915-912	1907 Large Liquid Valve & Actuator
8915-914	1907 Large Liquid Valve & Actuator
8915-915	1907 Large Liquid Valve & Actuator
8915-916	3171 Valve c/w EM35 Actuator

8915-917	3103 Valve c/w EM35 Actuator
8915-918	3103 Valve c/w EM35 Actuator
8915-919	3103 Valve c/w EM35 Actuator
8915-921	3103 Valve c/w EM35 Actuator
8915-922	3171 Valve c/w EM35 Actuator
8915-930	3103 Valve c/w TM55 Actuator
8915-948	3151A WATER VALVE
8915-953	3103 Valve c/w EM35 Actuator
8915-955	3103 Valve c/w EM35 Actuator
8915-964	3103 Valve c/w EM35 Actuator
8915-969	3103 Valve c/w EM35 Actuator
8915-970	3103 Valve c/w EM35 Actuator
8915-971	3103 Valve c/w EM35 Actuator
8915-972	3103 Valve c/w EM35 Actuator
8915-973	3103 Valve c/w EM35 Actuator
8915-976	3103 Valve c/w EM35 Actuator
8915-977	3171 Valve c/w Actuator
8915-978	3171 Valve c/w EM35MR1 Actuator
8915-980	3103 Valve c/w TM55 Actuator
8915-988	3151A WATER VALVE
8915-989	3151A WATER VALVE
8915-995	3103/3171 Valve c/w TM100 Actuator
8915-998	3103 Valve c/w TM55 Actuator
8915-999	3103 Valve c/w EM35 Actuator
8918-065	3171 FLOW LEG
8918-066	3171 FLOW LEG
8918-082	Gas Shut Off Valve
8918-097	GS6 FLOW LEG
8918-223	3171 FLOW LEG
8918-240	3171 FLOW LEG
8918-246	3171 FLOW LEG
8918-247	3171 FLOW LEG
8923-1385	GFCV (6" HR)
8923-1675	LQ25 VALVE
8928-7231	GFCV (2" IR)
9016M58P06	LM2500 LIQUID FUEL NOZZLE
9016M58P25	LM2500 LIQUID FUEL NOZZLE (LOW SMOKE)
9016M58P26	LM2500 LIQUID FUEL NOZZLE (LOW SMOKE)
9016M58P27	LM2500 LIQUID FUEL NOZZLE
9059430-386	IGNITOR CABLE
9691M29P15 - Superseded s	VSV Actuator
9691M29P17 - Superseded s	VSV Actuator
9691M29P19	ACTUATOR, VSV
9691M29P19	VSV Actuator
9691M29P25	ACTUATOR, VSV
9691M29P25	VSV Actuator
9900-532	LQ25 VALVE

9902-042	3055 PUMP
9902-072	3055 PUMP
9902-221	3055 PUMP
9902-222	VG Electrohydraulic Servo Valve
9902-263	3055 PUMP
9902-265	3103 Valve c/w TM55 Actuator
9902-279	VSV Controller (Hydro-mechanical)
9902-325	1907 Large Liquid Valve & Actuator
9902-332	VSV Controller (Hydro-mechanical)
9902-337	Hydraulic Control Unit
9902-338	VG Electrohydraulic Servo Valve
9902-339	Hydraulic Control Unit
9902-343	Hydraulic Control Unit
9902-363	Remote Servos & Rams
9902-364	Hydraulic Control Unit
9902-365	Hydraulic Control Unit
9902-373	Remote Servos & Rams
9902-374	Remote Servos & Rams
9902-380	VG Electrohydraulic Servo Valve
9902-398	3055 PUMP
9902-399	VG Controller (Electro-hydraulic)
9902-400	VG Controller (Electro-hydraulic)
9902-401	VG Controller (Electro-hydraulic)
9902-402	VG Electrohydraulic Servo Valve
9902-403	VG Electrohydraulic Servo Valve
9902-404	VG Electrohydraulic Servo Valve
9902-405	VSV Controller (Hydro-mechanical)
9902-406	VSV Controller (Hydro-mechanical)
9902-407	Remote Servos & Rams
9902-408	Remote Servos & Rams
9902-409	VG Controller (Electro-hydraulic)
9902-410	VG Controller (Electro-hydraulic)
9902-411	VG Controller (Electro-hydraulic)
9902-412	VG Electrohydraulic Servo Valve
9902-413	VG Electrohydraulic Servo Valve
9902-414	VG Electrohydraulic Servo Valve
9902-428	3055 PUMP
9902-429	VG Controller (Electro-hydraulic)
9902-430	VG Controller (Electro-hydraulic)
9902-431	VG Controller (Electro-hydraulic)
9902-439	VG Controller (Electro-hydraulic)
9902-440	VG Controller (Electro-hydraulic)
9902-441	VG Controller (Electro-hydraulic)
9902-450	Remote Servos & Rams
9902-451	Remote Servos & Rams
9902-471	VG Controller (Electro-hydraulic)
9902-700	VG Controller (Electro-hydraulic)

9902-701	Hydraulic Control Unit
9904-060	TM 25/200 LINEAR ACTUATOR
9904-1069	SRV (4" V300)
9904-1071	GFCV (2" SR)
9904-1079	GFCV (2" SR)
9904-1082	GFCV (2" SR)
9904-1094	GFCV (3" SR)
9904-1097	GFCV (3" SR)
9904-1104	GFCV (3" SR)
9904-1105	GFCV (3" SR)
9904-1112	GFCV (4" SR)
9904-1114	GFCV (6" SR)
9904-1115	GFCV (6" SR)
9904-1117	GFCV (6" SR)
9904-1120	GFCV (6" SR)
9904-1128	GFCV (2" SR)
9904-1147	SRV (6" SS260)
9904-1150	SRV (8" SS260)
9904-1151	SRV (8" SS260)
9904-1152	SRV (8" SS260)
9904-1153	SRV (8" SS260)
9904-1166	GFCV (3" HR)
9904-1167	GFCV (3" HR)
9904-1169	GFCV (3" HR)
9904-1170	GFCV (3" HR)
9904-1180	GFCV (4" HR)
9904-1181	GFCV (4" HR)
9904-1185	GFCV (6" HR)
9904-1189	GFCV (6" HR)
9904-1191	GFCV (6" HR)
9904-1192	GFCV (6" HR)
9904-1194	GFCV (6" HR)
9904-1205	HYD IGVA - BASE MOUNT
9904-1207	HYD IGVA - BASE MOUNT
9904-1212	GFCV (2" HR)
9904-1224	SRV (10" V300)
9904-1241	SRV (6" V300)
9904-1243	GFCV (2" SR)
9904-1244	GFCV (3" SR)
9904-1245	GFCV (4" SR)
9904-1246	GFCV (6" SR)
9904-1247	GFCV (3" HR)
9904-1248	GFCV (3" HR)
9904-1249	GFCV (4" HR)
9904-1250	GFCV (6" HR)
9904-1251	GFCV (2" HR)
9904-1252	GFCV (3" HR)



9904-1253	GFCV (6" HR)
9904-1257	GFCV (2" HR)
9904-1258	GFCV (3" HR)
9904-1259	GFCV (3" HR)
9904-1263	GFCV (4" HR)
9904-1264	GFCV (6" HR)
9904-1270	SRV (6" V300)
9904-1274	HYD IGVA - BASE MOUNT
9904-1278	GFCV (3" HR)
9904-1279	GFCV (4" HR)
9904-1280	SRV (8" SS260)
9904-1281	Liquid Shut Off Valve
9904-1283	SRV (8" SS260)
9904-1285	SRV (8" SS260)
9904-1286	SRV (8" SS260)
9904-1292	SRV (6" SS260)
9904-1298	GFCV (2" HR)
9904-130	1907 Small Gas Valve
9904-1306	GFCV (3" SR)
9904-1330	HYD IGVA - BASE MOUNT
9904-1335	GFCV (4" SR)
9904-1336	GFCV (3" SR)
9904-1343	SRV (8" V300)
9904-1355	SRV (8" SS260)
9904-1356	GFCV (3" HR)
9904-1362	GFCV (2" IR)
9904-1363	SRV (4" V300)
9904-1364	GFCV (4" SR)
9904-1365	GFCV (2" IR)
9904-1367	GFCV (2" HR)
9904-1369	SRV (3" V300)
9904-1370	SRV (8" SS260)
9904-1384	GFCV (6" HR)
9904-1388	GFCV (6" HR)
9904-1400	GFCV (6" HR)
9904-1401	GFCV (6" HR)
9904-1404	GFCV (6" HR)
9904-1406	GFCV (6" SR)
9904-1407	GFCV (6" HR)
9904-1408	GFCV (6" HR)
9904-1410	GFCV (6" HR)
9904-1411	GFCV (6" HR)
9904-1412	GFCV (6" HR)
9904-1416	SRV (8" SS260)
9904-1426	SRV (6" SS260)
9904-1427	GFCV (6" SR)
9904-1428	GFCV (6" HR)

9904-1443	SRV (6" SS260)
9904-1444	GFCV (2" HR)
9904-1448	HYD IGVA - BASE MOUNT
9904-1450	GFCV (2" HR)
9904-1451	GFCV (2" HR)
9904-1452	GFCV (3" HR)
9904-1453	GFCV (2" HR)
9904-1454	SRV (4" V300)
9904-1455	GFCV (6" SR)
9904-1456	GFCV (3" SR)
9904-1457	GFCV (4" SR)
9904-1458	SRV (6" V300)
9904-1463	SRV (4" V300)
9904-1470	SRV (8" SS260)
9904-268	LARGE HYD 3-WAY VALVE
9904-506	GFCV (2" SR)
9904-509	LARGE HYD 3-WAY VALVE
9904-510	LARGE HYD 3-WAY VALVE
9904-511	SRV (4" V300)
9904-512	SRV (6" V300)
9904-513	GFCV (6" SR)
9904-516	Liquid Shut Off Valve
9904-518	LARGE HYD 3-WAY VALVE
9904-519	LARGE HYD 3-WAY VALVE
9904-524	GFCV (3" SR)
9904-532	Gas Shut Off Valve
9904-533	HYD IGVA - BASE MOUNT
9904-534	Gas Shut Off Valve
9904-540	GFCV (2" SR)
9904-541	GFCV (3" SR)
9904-545	GFCV (3" SR)
9904-549	Gas Shut Off Valve
9904-551	GFCV (3" SR)
9904-558	LARGE HYD 3-WAY VALVE
9904-568	LARGE HYD 3-WAY VALVE
9904-570	Liquid Shut Off Valve
9904-574	LARGE HYD 3-WAY VALVE
9904-575	LARGE HYD 3-WAY VALVE
9904-580	SRV (4" V300)
9904-581	Gas Shut Off Valve
9904-585	GFCV (2" SR)
9904-593	GFCV (4" SR)
9904-594	SRV (8" V300)
9904-595	GFCV (3" SR)
9904-596	SRV (3" V300)
9904-597	GFCV (3" SR)
9904-629	HYD IGVA - BASE MOUNT

9904-700	SRV (6" SS260)
9904-702	SRV (6" V300)
9904-704	GFCV (2" SR)
9904-710	SRV (8" V300)
9904-712	GFCV (3" SR)
9904-716	SRV (4" V300)
9904-725	GFCV (4" SR)
9904-726	GFCV (4" SR)
9904-727	GFCV (6" SR)
9904-728	GFCV (4" SR)
9904-729	GFCV (6" SR)
9904-730	GFCV (6" SR)
9904-731	GFCV (6" SR)
9904-737	GFCV (4" IR)
9904-738	GFCV (4" IR)
9904-750	SRV (8" V300)
9904-751	SRV (6" V300)
9904-753	SRV (6" SS260)
9904-756	GFCV (4" IR)
9904-768	SRV (3" V300)
9904-769	SRV (4" V300)
9904-771	SRV (6" V300)
9904-773	SRV (6" SS260)
9904-774	SRV (8" V300)
9904-776	SRV (8" V300)
9904-778	SRV (8" V300)
9904-779	SRV (6" SS260)
9904-785	SRV (4" V300)
9904-904	SRV (8" V300)
9904-907	SRV (3" V300)
9904-908	SRV (3" V300)
9904-909	SRV (3" V300)
9904-910	SRV (4" V300)
9904-911	SRV (6" V300)
9904-913	SRV (6" V300)
9904-925	GFCV (3" SR)
9904-926	SRV (3" V300)
9904-928	GFCV (2" HR)
9904-930	GFCV (2" HR)
9904-931	GFCV (2" HR)
9904-935	SRV (6" V300)
9904-936	GFCV (3" SR)
9904-937	GFCV (4" SR)
9904-938	GFCV (6" SR)
9904-966	HYD IGVA - BASE MOUNT
9904-989	HYD IGVA - BASE MOUNT
9905-169	TM 25/200 LINEAR ACTUATOR

9905-218	1907 Small Gas Valve
9905-268	TM 25/200 LINEAR ACTUATOR
9905-269	TM 25/200 LINEAR ACTUATOR
9905-450	Gas Shut Off Valve
9905-651	TM 25/200 LINEAR ACTUATOR
9905-654	TM 25/200 LINEAR ACTUATOR
9905-656	TM 25/200 LINEAR ACTUATOR
9905-657	TM 25/200 LINEAR ACTUATOR
9905-658	TM 25/200 LINEAR ACTUATOR
9905-659	TM 25/200 LINEAR ACTUATOR
9905-660	TM 25/200 LINEAR ACTUATOR
9905-661	TM 25/200 LINEAR ACTUATOR
9905-664	TM 25/200 LINEAR ACTUATOR
9905-665	TM 25/200 LINEAR ACTUATOR
9905-667	TM 25/200 LINEAR ACTUATOR
9905-669	TM 25/200 LINEAR ACTUATOR
9905-763	TM 25/200 LINEAR ACTUATOR
9905-764	TM 25/200 LINEAR ACTUATOR
9905-765	TM 25/200 LINEAR ACTUATOR
9905-766	TM 25/200 LINEAR ACTUATOR
9905-767	TM 25/200 LINEAR ACTUATOR
9905-773	TM 25/200 LINEAR ACTUATOR
9905-915	Remote Servos & Rams
9907-072	24V POWER SUPPLY
9907-1100	CPC-II Convertors (Zone 1 & 2)
9907-1102	CPC-II Convertors (Zone 2)
9907-1103	CPC-II Convertors (Zone 1 & 2)
9907-1104	LQ25 VALVE
9907-1106	CPC-II Convertors (Zone 2)
9907-1135	LQ25 VALVE
9907-1136	LQ25 VALVE
9907-1139	GFCV (2" SR)
9907-1140	LQ25 VALVE
9907-1197	CPC-II Convertors (Zone 1 & 2)
9907-1198	CPC-II Convertors (Zone 2)
9907-1199	CPC-II Convertors (Zone 1 & 2)
9907-1200	CPC-II Convertors (Zone 2)
9907-126	EM35 DIGITAL DRIVER
9907-256	GFCV (2" SR)
9907-257	SRV (3" V300)
9907-260	LQ25 VALVE
9907-302	Gas Shut Off Valve
9907-304	Gas Shut Off Valve
9907-306	Gas Shut Off Valve
9907-314	Gas Shut Off Valve
9907-321	LQ25 VALVE
9907-351	LQ25 VALVE

9907-354	LQ25 VALVE
9907-355	LQ25 VALVE
9907-361	LQ25 VALVE
9907-363	LQ25 VALVE
9907-487	Gas Shut Off Valve
9907-504	LQ25T VALVE
9907-514	GS6 Valve
9907-515	GS6 Valve
9907-516	GS6 Valve
9907-517	GS6 Valve
9907-525	SRV (3" V300)
9907-526	GS16 VALVE
9907-528	GS16 VALVE
9907-537	GS16 VALVE
9907-553	GS16 VALVE
9907-558	GS6 Valve
9907-559	GS6 Valve
9907-561	GS16 VALVE
9907-571	GS6 Valve
9907-572	GS16 VALVE
9907-573	GS16 VALVE
9907-575	GS16 VALVE
9907-576	GS6 Valve
9907-587	GFCV (2" SR)
9907-589	SRV (3" V300)
9907-600	Gas Shut Off Valve
9907-646	LQ25 VALVE
9907-652	LQ25 VALVE
9907-661	GS6 Valve
9907-662	GS6 Valve
9907-667	GS6 Valve
9907-668	GS6 Valve
9907-670	Liquid Shut Off Valve
9907-671	GS10 Valve
9907-672	GS10 Valve
9907-687	GS16 VALVE
9907-690	GFCV (2" SR)
9907-696	LQ25 VALVE
9907-861	Gas Shut Off Valve
9907-869	Universal Shut off Valve
9907-870	Universal Shut off Valve
9907-895	Gas Shut Off Valve
9907-896	Gas Shut Off Valve
9907-898	Gas Shut Off Valve
9907-899	Gas Shut Off Valve
9907-954	GS6 Valve
9907-955	EM35 ACTUATOR

9907-977	GS6 Valve
9907-980	Gas Shut Off Valve
9907-994	LQ25 VALVE
9907-995	LQ25 VALVE
9907-996	LQ25 VALVE
9907-997	Liquid Shut Off Valve
9907-999	LQ25 VALVE
9908-011	VSV Controller (Hydro-mechanical)
9908-023	VSV Controller (Hydro-mechanical)
9908-027	LQ3 VALVE
9908-138	HYD IGVA - BASE MOUNT SIEMENS
9908-193	HYD IGVA - BASE MOUNT SIEMENS
9908-194	HYD IGVA - BASE MOUNT SIEMENS
9908-199	HYD IGVA - BASE MOUNT SIEMENS
9908-200	LQ25T VALVE
9908-201	LQ25T VALVE
9908-202	LQ25 VALVE
9908-203	LQ25T VALVE
9908-204	LQ25T VALVE
9908-205	LQ25T VALVE
9908-208	LQ25T VALVE
9908-209	LQ25 VALVE
9908-210	LQ25 VALVE
9908-211	LQ25T VALVE
9908-212	LQ25T VALVE
9908-216	LQ25 VALVE
9908-217	LQ25 VALVE
9908-261	GS10 Valve
9908-263	GS16 VALVE
9908-265	GS16 VALVE
9908-266	GS16 VALVE
9908-269	GS16 VALVE
9908-270	GS16 VALVE
9908-272	GS6 Valve
9908-276	LQ3 VALVE
9908-277	GS6 Valve
9908-278	GS6 Valve
9908-325	TM 25/200 LINEAR ACTUATOR
9908-328	TM 25/200 LINEAR ACTUATOR
9908-329	TM 25/200 LINEAR ACTUATOR
9908-334	TM 25/200 LINEAR ACTUATOR
9908-352	Liquid Shut Off Valve
9908-354	Liquid Shut Off Valve
9908-399	TM 25/200 LINEAR ACTUATOR
9908-400	TM 25/200 LINEAR ACTUATOR
9908-402	LQ25 VALVE
9908-405	LQ25 VALVE

9908-407	LQ25 VALVE
9908-410	LQ25 VALVE
9908-412	LQ25 VALVE
9908-413	LQ25 VALVE
9908-415	LQ25 VALVE
9908-512	HYD IGVA - BASE MOUNT SIEMENS
9908-513	HYD IGVA - BASE MOUNT SIEMENS
AS1895/7-200	SEAL
FS-9000-LP	UV LIGHT PEN
GK34/S4	GK34/S4 DRESSER
IQQ040080512	HIMATRIX F35 03 SILWORK
IRR371060413	CABLE: TYPE EXTENSION
L21275G02	FUEL MANIFOLD
L21275G04	FUEL MANIFOLD
L21564G01	Manifold, Oil - Lube Pump Spline
L24365P01	LM2500 DUAL FUEL NOZZLE
L24365P02	LM2500 DUAL FUEL NOZZLE
L24365P03	LM2500 DUAL FUEL NOZZLE
L24366G01	FUEL MANIFOLD
L24366G02	FUEL MANIFOLD
L25833P04	VSV Controller (Hydro-mechanical)
L28490P05	LM2500 FLAME DETECTORS
L31048P10	LM2500 GAS/WATER NOZZLE
L31048P11	LM2500 GAS/WATER NOZZLE
L31048P12	LM2500 GAS/WATER NOZZLE
L31048P13	LM2500 GAS/WATER NOZZLE
L31048P14	LM2500 GAS/WATER NOZZLE
L31048P15	LM2500 GAS/WATER NOZZLE
L31421P03	LM2500 DUAL FUEL NOZZLE
L31421P04	LM2500 DUAL FUEL NOZZLE
L31421P07	LM2500 DUAL FUEL NOZZLE
L31421P10	LM2500 DUAL FUEL NOZZLE
L31476P43	LM6000 GAS/WATER NOZZLE
L31476P47	LM6000 GAS/WATER NOZZLE
L31476P51	LM6000 GAS/WATER NOZZLE
L31476P56	LM6000 GAS/WATER NOZZLE
L31476P59	LM6000 DUAL FUEL NOZZLE
L31476P60	LM6000 DUAL FUEL NOZZLE
L31476P61	LM6000 DUAL FUEL NOZZLE
L31476P62	LM6000 DUAL FUEL NOZZLE
L31476P63	LM6000 DUAL FUEL NOZZLE
L31476P64	LM6000 DUAL FUEL NOZZLE
L31476P65	LM6000 DUAL FUEL NOZZLE
L31476P66	LM6000 DUAL FUEL NOZZLE
L31476P67	LM6000 DUAL FUEL NOZZLE
L31476P68	LM6000 DUAL FUEL NOZZLE
L31725P01	LM1600 DUAL FUEL NOZZLE

L31725P05	LM1600 GAS/WATER NOZZLE
L31725P06	LM1600 DUAL FUEL NOZZLE
L31725P07	LM1600 GAS/WATER NOZZLE
L31729G03	LM1600 GAS NOZZLE
L31736G07	LM6000 STIG (DUAL CIRCUIT) NOZZLE
L31736G08	LM6000 STIG (DUAL CIRCUIT) NOZZLE
L31736G09	LM6000 STIG (DUAL CIRCUIT) NOZZLE
L31736G10	LM6000 STIG (DUAL CIRCUIT) NOZZLE
L31736G11	LM6000 STIG (DUAL CIRCUIT) NOZZLE
L31736G12	LM6000 STIG (DUAL CIRCUIT) NOZZLE
L31805G05	LM2500 STIG (DUAL CIRCUIT) NOZZLE
L31805G09	LM2500 STIG (DUAL CIRCUIT) NOZZLE
L31809P01	LM2500 DUAL FUEL NOZZLE
L31809P02	LM2500 GAS/WATER NOZZLE
L31809P03	LM2500 DUAL FUEL NOZZLE
L31809P04	LM2500 GAS/WATER NOZZLE
L31809P05	LM2500 DUAL FUEL NOZZLE
L31809P06	LM2500 GAS/WATER NOZZLE
L31809P07	LM2500 DUAL FUEL NOZZLE
L31809P08	LM2500 GAS/WATER NOZZLE
L31809P09	LM2500 DUAL FUEL NOZZLE
L31809P10	LM2500 DUAL FUEL NOZZLE
L31809P11	LM2500 DUAL FUEL NOZZLE
L31809P12	LM2500 DUAL FUEL NOZZLE (enlarged shrouds)
L31809P13	LM2500 DUAL FUEL NOZZLE (enlarged shrouds)
L31809P14	LM2500 DUAL FUEL NOZZLE (enlarged shrouds)
L31810G01	LM2500 GAS NOZZLE
L31810G02	LM2500 GAS NOZZLE
L31810G03	LM2500 GAS NOZZLE
L31810G04	LM2500 GAS NOZZLE
L31810G05	LM2500 GAS NOZZLE
L31810G06	LM2500 GAS NOZZLE
L31810G07	LM2500 GAS NOZZLE
L31957G01	LM2500 STIG (PREMIXED) NOZZLE
L31957G02	LM2500 STIG (PREMIXED) NOZZLE
L31957G03	LM2500 STIG (PREMIXED) NOZZLE
L31967P25	ACCELEROMETER
L31971G01	LM1600 STIG (PREMIXED) NOZZLE
L34340G01	FUEL FEEDER TUBE
L34356P03	VG Electrohydraulic Servo Valve
L34366G01	FUEL TUBE
L34379P02	VSV Controller (Hydro-mechanical)
L34379P03	VSV Controller (Hydro-mechanical)
L34379P04	VSV Controller (Hydro-mechanical)
L34714G01	FUEL MANIFOLD
L34716G01	FUEL MANIFOLD
L34732G01	FUEL TUBE



L34745G01	FUEL MANIFOLD
L34868G01	FUEL TUBE
L35220G02	FUEL TUBE
L38023P01	LM6000 DLE 2-CUP PREMIXER
L38024P01	LM6000 DLE 3-CUP PREMIXER
L38054P01	LM6000 DLE 2-CUP PREMIXER
L38055P01	LM6000 DLE 3-CUP PREMIXER
L38056P02	LM6000 DLE 2-CUP PREMIXER
L38057P02	LM6000 DLE 3-CUP PREMIXER
L38059P01	LM2500 DUAL FUEL NOZZLE
L38059P02	LM2500 DUAL FUEL NOZZLE
L38059P03	LM2500 DUAL FUEL NOZZLE
L38059P04	LM2500 DUAL FUEL NOZZLE
L38059P05	LM2500 DUAL FUEL NOZZLE
L38059P06	LM2500 DUAL FUEL NOZZLE
L38059P07	LM2500 DUAL FUEL NOZZLE
L38059P08	LM2500 DUAL FUEL NOZZLE
L38059P09	LM2500 DUAL FUEL NOZZLE
L38061P01	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38061P02	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38061P03	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38061P04	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38062P01	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38062P02	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38062P03	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38062P04	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38086P01	LM2500 DLE 2-CUP PREMIXER (Railed)
L38087P02	LM2500 DLE 3-CUP PREMIXER (Railed)
L38098P01	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38098P02	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38100P01	LM2000 DLE 2-CUP PREMIXER
L38101P01	LM2000 DLE 3-CUP PREMIXER
L38102P01	LM6000 DLE 2-CUP PREMIXER
L38102P02	LM6000 DLE 2-CUP PREMIXER
L38102P03	LM6000 DLE 2-CUP PREMIXER
L38102P04	LM6000 DLE 2-CUP PREMIXER
L38103P01	LM6000 DLE 3-CUP DAMP PREMIXER
L38103P02	LM6000 DLE 3-CUP DAMP PREMIXER
L38103P03	LM6000 DLE 3-CUP DAMP PREMIXER
L38103P04	LM6000 DLE 3-CUP DAMP PREMIXER
L38107P01	LM2500 DLE 3-CUP DUAL FUEL PREMIXER
L38107P02	LM2500 DLE 3-CUP DUAL FUEL PREMIXER
L38107P03	LM2500 DLE 3-CUP DUAL FUEL PREMIXER
L38145P01	LM2500 DLE 2-CUP DUAL FUEL PREMIXER
L38145P02	LM2500 DLE 3-CUP DUAL FUEL PREMIXER
L38145P03	LM2500 DLE 3-CUP DUAL FUEL PREMIXER
L38165P02	LM6000 DLE 2-CUP PREMIXER (Railed)

L38165P04	LM6000 DLE 2-CUP PREMIXER (Railed)
L38165P07	LM6000 DLE 2-CUP PREMIXER (Railed)
L38165P08	LM6000 DLE 2-CUP PREMIXER (Railed)
L38166P02	LM6000 DLE 3-CUP PREMIXER (Railed)
L38166P04	LM6000 DLE 3-CUP PREMIXER (Railed)
L38240P01	LMS100 DUAL FUEL NOZZLE
L38240P02	LMS100 DUAL FUEL NOZZLE
L38240P03	LMS100 DUAL FUEL NOZZLE
L38240P04	LMS100 DUAL FUEL NOZZLE
L38240P05	LMS100 DUAL FUEL NOZZLE
L38240P06	LMS100 DUAL FUEL NOZZLE
L38240P07	LMS100 DUAL FUEL NOZZLE
L38340P01	LMS100 2-CUP PREMIXER
L38340P02	LMS100 2-CUP PREMIXER
L38340P03	LMS100 2-CUP PREMIXER
L38340P04	LMS100 2-CUP PREMIXER
L38340P05	LMS100 2-CUP PREMIXER
L38362P01	LM2500 DLE 3-CUP PREMIXER (Railed)
L38362P02	LM2500 DLE 3-CUP PREMIXER (Railed)
L38362P03	LM2500 DLE 3-CUP PREMIXER (Railed)
L38363P01	LM2500 DLE 2-CUP PREMIXER (Railed)
L38363P02	LM2500 DLE 2-CUP PREMIXER (Railed)
L38363P03	LM2500 DLE 2-CUP PREMIXER (Railed)
L38584P01	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38584P02	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38584P03	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38584P04	LM6000 DLE 2-CUP DUAL FUEL PREMIXER
L38585P01	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38585P02	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38585P03	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38585P04	LM6000 DLE 3-CUP DUAL FUEL PREMIXER
L38631P01	LM2500 DUAL FUEL NOZZLE
L38631P02	LM2500 DUAL FUEL NOZZLE
L38638P01	LM2500 LIQUID NOZZLE
L38719P01	LM6000 DUAL FUEL NOZZLE
L38719P03	LM6000 DUAL FUEL NOZZLE
L38756P01	LMS100 GAS/WATER NOZZLE
L38756P03	LMS100 GAS/WATER NOZZLE
L38784P01	LM2500 GAS/WATER NOZZLE
L43064P01	LM6000 LIQUID FUEL NOZZLE
L43064P02	LM6000 LIQUID FUEL NOZZLE
L43064P04	LM6000 LIQUID FUEL NOZZLE
L43064P05	LM6000 LIQUID FUEL NOZZLE
L43064P07	LM6000 LIQUID FUEL NOZZLE
L43064P08	LM6000 LIQUID FUEL NOZZLE
L43064P09	LM6000 LIQUID FUEL NOZZLE
L43064P10	LM6000 LIQUID FUEL NOZZLE

L43418P02 - Superseded see	VSV / IGV Actuator
L43418P03	VSV ACTUATOR
L43418P03	ACTUATOR, VSV/VIGV
L43418P03	VSV / IGV Actuator
L43418P04	VSV / IGV Actuator
L43418P06	ACTUATOR
L43418P06	VSV Actuator
L43418P07	ACTUATOR
L43418P07	VSV / IGV Actuator
L43419P04 - Superseded see	VBV Actuator with LVDT
L43419P07	VBV ACTUATOR WITH LVDT
L43419P07	ACTUATOR
L43419P07	VBV Actuator with LVDT
L43420P04 - Superseded see	VBV Actuator without LVDT
L43420P05 - Superseded see	VBV Actuator without LVDT
L43420P06 - Superseded see	VBV Actuator without LVDT
L43420P07	ACTUATOR
L43420P07	VBV Actuator without LVDT
L43565G01	LM1600 STIG DUAL FUEL NOZZLE
L44093P02	LM1600 DLE 2-CUP PREMIXER
L44500P09	LUBE & SCAVENGE PUMP
L44500P10	LUBE & SCAVENGE PUMP
L44500P11	LUBE & SCAVENGE PUMP
L44500P12	LUBE & SCAVENGE PUMP
L44500P13	LUBE & SCAVENGE PUMP
L44500P14	LUBE & SCAVENGE PUMP
L44500P15	LUBE & SCAVENGE PUMP
L44500P16	LUBE & SCAVENGE PUMP
L44500P17	LUBE & SCAVENGE PUMP
L44569P07	VG Electrohydraulic Servo Valve
L44569P11	VG Controller (Electro-hydraulic)
L44569P12	VG Controller (Electro-hydraulic)
L44569P14	VG Controller (Electro-hydraulic)
L44569P15	VG Controller (Electro-hydraulic)
L44569P16	VG Electrohydraulic Servo Valve
L44569P17	VG Electrohydraulic Servo Valve
L44569P18	VG Electrohydraulic Servo Valve
L44569P19	VG Controller (Electro-hydraulic)
L44569P20	VG Controller (Electro-hydraulic)
L44569P21	VG Controller (Electro-hydraulic)
L44569P22	VG Electrohydraulic Servo Valve
L44569P23	VG Electrohydraulic Servo Valve
L44569P24	VG Electrohydraulic Servo Valve
L44569P26	VG Controller (Electro-hydraulic)
L44569P27	VG Controller (Electro-hydraulic)
L44569P28	VG Controller (Electro-hydraulic)
L44569P29	VG Controller (Electro-hydraulic)

L44569P30	VG Controller (Electro-hydraulic)
L44569P31	VG Controller (Electro-hydraulic)
L44569P38	VG Controller (Electro-hydraulic)
L44819P01	FLAME SENSOR (UV)
L45730G02	FUEL MANIFOLD
L45731G02	FUEL MANIFOLD
L45732G02	FUEL MANIFOLD
L45733G02	FUEL MANIFOLD
L45881P04	FUEL TUBE
L45882P04	FUEL TUBE
L45970G01	FUEL TUBE
L45972G01	FUEL FEEDER TUBE
L46301G01	FUEL TUBE
L46380G01	FUEL FEEDER TUBE
L46466G01	FUEL FEEDER TUBE
L46474G01	FUEL MANIFOLD
L47191P01	LM6000 DLE 2-CUP PREMIXER
L47191P02	LM6000 DLE 2-CUP PREMIXER
L47191P03	LM6000 DLE 2-CUP PREMIXER
L47191P04	LM6000 DLE 2-CUP PREMIXER
L47191P05	LM6000 DLE 2-CUP PREMIXER
L47191P06	LM6000 DLE 2-CUP PREMIXER
L47192P01	LM6000 DLE 3-CUP PREMIXER
L47192P02	LM6000 DLE 3-CUP PREMIXER
L47192P03	LM6000 DLE 3-CUP PREMIXER
L47192P04	LM6000 DLE 3-CUP PREMIXER
L47197P05	LM2500 DLE 2-CUP PREMIXER
L47197P06	LM2500 DLE 2-CUP PREMIXER
L47198P02	LM2500 DLE 3-CUP PREMIXER
L47198P03	LM2500 DLE 3-CUP PREMIXER
L47328P02	BLEED VALVE (4 INCH)
L47329P05	BLEED VALVE (2.5 INCH)
L47330P04	BLEED VALVE (6 INCH)
L47449P01	LM2500 STIG DUAL FUEL NOZZLE (PREMIXED)
L47450P01	LM2500 BIOMASS NOZZLE
L47465P01	LM2500 DUAL FUEL NOZZLE
L47465P02	LM2500 DUAL FUEL NOZZLE
L47465P03	LM2500 DUAL FUEL NOZZLE
L47465P04	LM2500 DUAL FUEL NOZZLE
L47465P05	LM2500 DUAL FUEL NOZZLE
L47465P06	LM2500 DUAL FUEL NOZZLE
L47465P07	LM2500 DUAL FUEL NOZZLE
L47551G01	LM2500 STIG (PREMIXED) NOZZLE
L47551G02	LM2500 STIG (PREMIXED) NOZZLE
L47572P01	6 PACK LPT STAGE 2 BLADES
L47636P02	LM6000 DLE 2-CUP PREMIXER
L47647P01	LM6000 DLE 2-CUP PREMIXER

L47647P02	LM6000 DLE 2-CUP PREMIXER
L47647P03	LM6000 DLE 2-CUP PREMIXER
L47647P04	LM6000 DLE 2-CUP PREMIXER
L47647P05	LM6000 DLE 2-CUP PREMIXER
L47648P05	LM6000 DLE 3-CUP PREMIXER
L47648P06	LM6000 DLE 3-CUP PREMIXER
L47704P01	LM6000 DLE 3-CUP PREMIXER
L47704P02	LM6000 DLE 3-CUP PREMIXER
L47732P01	LM6000 DLE 2-CUP PREMIXER
L47733P01	LM6000 DLE 3-CUP PREMIXER
L49232G02	FUEL MANIFOLD
L49233G02	FUEL MANIFOLD
L49234G02	FUEL MANIFOLD
L49235G02	FUEL MANIFOLD
L49236G01	FUEL MANIFOLD
L49273P03	FUEL TUBE
L50666G07	BRKT, SHAFT-FWD
L51268P03	FUEL TUBE
L51269P03	FUEL TUBE
L51270P03	FUEL TUBE
L54001G01	FUEL MANIFOLD
L54002G01	FUEL MANIFOLD
L54003G01	FUEL TUBE
L54004G01	FUEL TUBE
L54005G01	FUEL TUBE
L54006G01	FUEL TUBE
L54007G01	FUEL TUBE
L54008G01	FUEL MANIFOLD
L54009G01	FUEL MANIFOLD
L54010G01	FUEL MANIFOLD
L54011G01	FUEL MANIFOLD
L54012G01	FUEL MANIFOLD
L54014G01	FUEL TUBE
L54015G01	FUEL TUBE
L54016G01	FUEL TUBE
L54017G01	FUEL TUBE
L54018G01	FUEL TUBE
L54019G01	FUEL MANIFOLD
L54020G01	FUEL MANIFOLD
L54021G01	FUEL MANIFOLD
L54022G01	FUEL MANIFOLD
L54025G01	FUEL TUBE
L54026G01	FUEL TUBE
L54027G01	FUEL TUBE
L54028G01	FUEL MANIFOLD
L54030G01	FUEL MANIFOLD
L54031G01	FUEL MANIFOLD

L54045G01	FUEL MANIFOLD
L54046G01	FUEL MANIFOLD
L54047G01	FUEL MANIFOLD
L54048G01	FUEL TUBE
L54049G01	FUEL TUBE
L54062G01	FUEL MANIFOLD
L54066G01	FUEL TUBE
L54067G01	FUEL TUBE
L54072G01	FUEL TUBE
L54084G01	FUEL MANIFOLD
L54088G01	FUEL MANIFOLD
L54106G01	FUEL TUBE
L54114G01	FUEL MANIFOLD
L54115G01	FUEL MANIFOLD
L54116G01	FUEL MANIFOLD
L54117G01	FUEL MANIFOLD
L54125G01	FUEL TUBE
L54129P01	FUEL HOSE ASSEMBLY
L54157P02	FUEL HOSE ASSEMBLY
L54390G01	FUEL MANIFOLD
L54393G01	FUEL MANIFOLD
L54394G01	FUEL MANIFOLD
L54395G01	FUEL MANIFOLD
L54396G01	FUEL MANIFOLD
L54402G01	FUEL MANIFOLD
L54403G01	FUEL MANIFOLD
L54404G01	FUEL MANIFOLD
L61065P01	LM2500+G4 Dual Fuel Nozzle
L61766P03	LM2500+G4 Dual Fuel Nozzle
L61766P04	LM2500+G4 Dual Fuel Nozzle
L61766P05	LM2500+G4 Dual Fuel Nozzle
L62021P02	LM6000 GROWTH DLE 2-CUP PREMIXER
L62629P01	SLW, SFT-FWD BRG
L62634G01	BRKT, BEARING, TRQ S
RS-E1-0039-003-MFR	FLAME SENSOR MOUNT TUBE, 1.5" long
RS-E2-0266G091	(4) RS-FS-9009-03 / (4) RS-E2-0285P004 / HARDWARE
RS-E2-0266G092	(4) RS-FS-9009-03 / (4) RS-E2-0285P004 / (1) RS-FSM-1002-002 / HARDWARE
RS-E2-0266G093	MOUNTING HARDWARE KIT for (2) RS-FS-9009-03 / RS-FS-9010-03
RS-E2-0266G094	(1) RS-FS-9100 / (1) RS-E2-0285P021 / HARDWARE
RS-E2-0266G097	(2) RS-FS-9009-03 / (2) RS-E2-0285P004 / (1) RS-FSM-1002-002 (1) RS-E1-0039-003 / HARDWARE
RS-E2-0266G098	(2) RS-FS-9009-03 / (2) RS-E2-0285P004 / (1) RS-E1-0039-003 / HARDWARE
RS-E2-0266G099	(8) RS-FS-9009-03 / (8) RS-E2-0285P004 / (2) RS-FSM-1002-002 / HARDWARE
RS-E2-0266G100	(8) RS-FS-9009-03 / (8) RS-E2-0285P004 / HARDWARE
RS-E2-0285P001	FLAME SENSOR CABLE: 60FT LONG / RIGHT ANGLE CONNECTOR GE P/N: 362A1053P001

RS-E2-0285P004	FLAME SENSOR CABLE: 120FT LONG / RIGHT ANGLE CONNECTOR GE P/N: 362A1053P004
RS-E2-0285P011	FLAME SENSOR CABLE: 60FT LONG / STRAIGHT CONNECTOR GE P/N: 362A1053P011
RS-E2-0285P012	FLAME SENSOR CABLE: 120FT LONG / STRAIGHT CONNECTOR GE P/N: 362A1053P012
RS-E2-0285P021	FLAME SENSOR CABLE: 15FT LONG / RIGHT ANGLE CONNECTOR GE P/N: 362A1053P021
RS-FS-9001	FLAME SENSOR (UV) - NA CLASS I DIV 2, ATEX ZONE 2 GE P/N: 362A1052P001 ITS PN: 184X0254M029
RS-FS-9004	FLAME SENSOR (UV) - NA CLASS I DIV 1, ATEX ZONE 1 GE P/N: 362A1052P106 ITS PN: 184X0254M123
RS-FS-9006-MFR	FLAME SENSOR (UV) - AERODERIVATIVE (AS9100) GE P/N: 362A1379P001
RS-FS-9009-03	FTD 325 - NA CLASS I DIV 2, ATEX ZONE 2 GE P/N: 124T5712P0001
RS-FS-9010-03	FTD 325 - NA CLASS I DIV 1, ATEX ZONE 1 GE P/N: 124T5712P0002
RS-FS-9100	FLAME TRACKER LITE FOR INDUSTRIAL APPLICATIONS
RS-FSM-1002-002	FLAME SENSOR MODULE FOR MKV
SMZ34900	SEAL, OUTER
SMZ34900	SEAL
SP-566	WATER COOLING COIL
<p><b>Updated: Jul 2022</b> <span style="float: right;"><b>Copyright 2020 Aero Controls</b></span></p>	